





QUICKSTART GUIDE

PRO-PIRAX


ON/OFF

1. Press the ON/OFF key to turn on the induction hob.
2. Choose the desired function by pressing the key . Each press of the button corresponds to each of the functions. The indicator light for each function will illuminate on the panel to indicate which one has been selected.
3. Select the desired temperature or power setting by pressing the   buttons (depending on the selected function you can adjust the temperature or power).


BRAISE

Select the function , the icon will light up and the hob will start to heat up to 2200W. You can adjust the power setting you want using the arrows (from 300W to 2200W).


STIR FRY

Select the function , the icon will light up and the hob will start to heat up to 2200W. You can adjust the power setting you want using the arrows (from 300W to 2200W).


DEEP FRY

Select the function , the icon will light up and the hob will start to heat up to 180°C. You can adjust the temperature you want using the arrows (from 80°C to 240°C).


BOILING

Select the function , the icon will light up and the hob will start to heat up to 2200W. The power setting **CANNOT** be adjusted when using this function.

SOUP

Select the function , the icon will light up and the hob will start to heat up to 1700W. The power setting **CANNOT** be adjusted when using this function.

WARM







Select the function , the icon will light up and the hob will start to heat up to 60°C. The temperature setting **CANNOT** be adjusted when using this function.



LOCK

1. Press the Lock key for 2 seconds to lock the induction hob.
2. The LED display will show the word LOC.
3. While in lock mode, the other keys will not work except Lock and Power key. You can turn off the hob with the power key but the Lock will not be deactivated.
4. Press the Lock key again for 2 seconds to exit lock mode.

TIMER

1. **Power-off timer:** Press the Power key, choose a function and when the induction hob starts up, press the  button to set the when you want the hob to turn off using the arrows  .
2. **Power-on timer:** Press the Power key, press the  button to set when you want the hob to turn on using the arrows  . Then choose a function (if you don't choose any of the cooking functions, the power-on timer will not work).

PAUSE

While the hob is working, press the key  to stop heating.
If you don't operate the appliance for 30 minutes, it will turn off automatically.

CREATE